


de Aufbausatz für AKF, ASF
 fr Kit de montage pour AKF, ASF
 en Mounting kit for AKF, ASF
 it Accoppiamento per AKF, ASF
 es Equipo de montaje para AKF, ASF
 sv Monteringsats för AKF, ASF
 nl Opbouwset voor AKF, ASF

de Montagevorschrift
 fr Instruction de montage
 en Fitting instructions
 it Istruzioni di montaggio
 es Instrucciones de montaje
 sv Montagevoorschrift
 nl Monteringsanvisning

0510240001

AKF, ASF

de Installationsanweisung für die Fachkraft / Monteur
 fr Conseils d'installation pour le spécialiste / monteur
 en Guidelines for the technician / fitter
 it Informazioni per il personale specializzato di montaggio
 es Instrucciones para el especialista del ramo / montador
 sv Installationsinstruktion för installatör / montör
 nl Installatietip voor de vakman / monteur




B11573


1 0510240001 + AKF, ASF

0510240001 + AKF, ASF


NC de NC (stromlos zu)
 fr NC (sans courant fermé)
 en NC (normally closed)
 it NC (senza corrente chiuso)
 es NC (sin corriente cerrado)
 sv NC (energilöst stängd)
 nl NC (stroomlos gesloten)




NO de NO (stromlos auf)
 fr NO (sans courant ouvert)
 en NO (normally open)
 it NO (senza corrente aperto)
 es NO (sin corriente abierto)
 sv NO (energilöst öppen)
 nl NO (stroomlos open)




2a VKR




B11251




2b BKR




B11252



3




3a **NC**



B11569

3b

NO



B11570



de	www.sauter-controls.com	⇒ Produkte	⇒ Material und Umweltdeklaration
fr	www.sauter-controls.com	⇒ Produits	⇒ Déclaration matériaux et environnement
en	www.sauter-controls.com	⇒ Products	⇒ Materialdeclaration
it	www.sauter-controls.com	⇒ Products	⇒ Materialdeclaration
es	www.sauter-controls.com	⇒ Products	⇒ Materialdeclaration
sv	www.sauter-controls.com	⇒ Products	⇒ Materialdeclaration
nl	www.sauter-controls.com	⇒ Products	⇒ Materialdeclaration

de Dokument aufbewahren
fr Ce document est à conserver
en Retain this document
it Conservare il documento
es Guardar el documento
sv Spara dokumentationen
nl Document bewaren

© Fr. Sauter AG
Im Surinam 55
CH-4016 Basel
Tel. +41 61 - 695 55 55
Fax +41 61 - 695 55 10
www.sauter-controls.com
info@sauter-controls.com